

## In situ supported VO<sub>x</sub> on carbon nanotubes for the low-temperature selective catalytic reduction of NO with NH<sub>3</sub>

W. Jin<sup>1</sup>, B. Jiao<sup>1</sup>, W. Chen<sup>2,\*</sup>, M. Li<sup>1</sup>, J. Zhao<sup>1</sup>, X. Zhang<sup>1</sup>

<sup>1</sup>State Key Laboratory of Silicate Materials for Architectures, Wuhan University of Technology, Wuhan 430070, P. R. China

<sup>2</sup>State Key Laboratory of Advanced Technology for Materials Synthesis and Processing, School of Materials Science and Engineering, Wuhan University of Technology, Wuhan 430070, P. R. China  
chenw@whut.edu.cn

Selective catalytic reduction (SCR) of NO<sub>x</sub> with NH<sub>3</sub> is nowadays considered as the most promising technology for the elimination of NO<sub>x</sub> [1]. As a typical commercial NH<sub>3</sub>-SCR catalyst, V<sub>2</sub>O<sub>5</sub>-WO<sub>3</sub>(MoO<sub>3</sub>)/TiO<sub>2</sub> catalysts are commonly used due to the high catalytic activity and SO<sub>2</sub> tolerance [2]. However, there are some unavoidable disadvantages in commercial V-Ti catalysts. For example, the active component is unevenly dispersed and easily detached from the surface of the carrier under the scouring of the flue gas, thus shortening the service life of the catalyst. In addition, the operating temperature of the V-Ti catalyst is relatively high, about 300-400 °C, and its catalytic activity is poor at low temperature. Therefore, it is extremely urgent to develop a SCR catalyst with high low temperature activity and good stability.

In order to solve the above problems, vanadium oxide was supported on the surface of the carbon nanotube by in-situ growth because the introduction of carbon nanotubes can improve the low temperature catalytic activity of the catalyst. And the in situ synthesis method can enhance the interaction between VO<sub>x</sub> and the carrier, thus enhancing the dispersion of VO<sub>x</sub>. In our work, the VO<sub>x</sub> were in situ supported on carbon nanotubes (CNTs) by a Cetylpyridinium Chloride (CPC) assisted reflux route. It was found that the in situ prepared catalyst exhibited better NH<sub>3</sub>-SCR activity at low temperature, better stability, higher SO<sub>2</sub>-tolerance and improved water-resistance than that of the catalysts prepared by impregnation or a mechanically mixed method. The EDS-mapping results indicated that the vanadium oxide species had good dispersion on the CNTs surface. The XPS results demonstrated that there were lower valence vanadium species (V<sup>4+</sup> and V<sup>3+</sup>) and chemisorbed oxygen species. According to the literatures, vanadium oxides with low valence states can easily adsorb oxygen to generate active oxygen species during SCR reaction, which is important to the low temperature SCR activity [3]. The H<sub>2</sub>-TPR results suggested that there was a strong interaction between the vanadium oxide on the surface of CNTs. The NH<sub>3</sub>-TPD results demonstrated that the catalysts presented a larger acid amount and stronger acid strength. The in situ prepared VO<sub>x</sub>/CNTs catalyst could be considered as a promising candidate for the low-temperature SCR of NO with NH<sub>3</sub>.




Figure 1. EDS-mapping of V<sub>2</sub>O<sub>5</sub>/CNTs catalyst.

1. D.S. Zhang, L. Zhang, L.Y. Shi, et al., *Nanoscale* **5**, 1127 (2013).
2. X.M. Zhou, X.Y. Huang, A.J. Xie, et al., *Chemical Engineering Journal* **326**, 1074 (2017).
3. H.F. Chen, Y.Xia, R.Y. Fang, et al., *Applied Surface Science* **459**, 639 (2018).